

Keyboard cover LapFlex

Protection foil
for Laptop-
Keyboard.



Easy to
handle.

The **LapFlex** keyboard cover is the safe and cost-effective solution for protecting the notebook. Depending on the model, the foil is stretched over the keyboard and protects the Notebook keyboard against splash water, production dirt, fat deposits or light chemical claim. The foil is the perfect solution for those who use the notebook in a doctor's office, in a laboratory, in the retail trade or in a manufacturing industry. Despite the keyboard cover, fans remain free and CD / DVD drives remain accessible, because the mounting is arranged by flexible elastic bands.

Benefits:

- › **Dirt & splash protection**
- › **Easy to clean**
- › **Disinfectable**
- › **Flexibel**
- › **Available in two sizes**

LapFlex

Application



1.



2.



3.

Life cycle • Cleaning • Disinfection

Depending on operational demands, the Uniflex cover may be used for up to three months. During its life time, the LapFlex cover may be used on different keyboards. Cleaning the LapFlex should be done only when the cover is pulled completely over the keyboard. To clean the LapFlex, take a slightly moistened cloth using warm water and soap, with 70% Isopropyl Alcohol you wipe the cover thoroughly for disinfection. Do not submerge the cover in water or wipe the inside as humidity will occur.

Damaged covers should be replaced immediately. Yellowing may be an indicator of product expiration.

Technical Data keyboard cover Lapflex

Type	M	L
Notebook size	14" up to 15"	15" up to 16"
Dimensions	345mm x 210mm	375mm x 240mm
Material	High-quality thermoplastic polyurethane (TPU)	High-quality thermoplastic polyurethane (TPU)
Life cycle	Approx. 3 months (depending on operational demands)	Approx. 3 months (depending on operational demands)
Minimum Order Quantity	10 foils	10 foils
Item No.	2006547	2006546